



FIELD INSTALLATION-POLYETHYLENE WRAP

STEP - 1 PALCE TUBE OF POLYETHYLENE MATERIAL AROUND PIPE PRIOR TO LOWERING PIPE INTO TRENCE

STEP - 2 PULL THE TUBE OVER THE LENGTH OF THE PIEP. TAPE TUBE TO PIPE AT JOINT. FOLD MATERIAL AROUND THE ADJACENT SPIGOT END AND WRAP WTIH THREE CIRCUMFERENTIAL TURNS OF TWO-INCH WIDE PLASTIC TAPE TO HOLD PLASTIC TUBE AROUND SPIGOT ENDS

STEP - 3 ADJACENT TUBE OVERLAPS FIRST TUBE AND IS SECURED WITH PLACTIC ADHESIVE TAPE. THE POLYETHYLENE TUBE MATERAIL COVERING THE PIPE WILL BE LOOSE. EXCESS MATERIAL SHALL BE NEATLY DRAWN UP AROUND THE PIPE BARREL, FOLDED INTO AN OVERLAP ON TOP OF THE PIPE AND HELD IN PLACE BY MEANS OF PIECES OF THE PLACTIC TAPE AT APPROXIMATELY THREE TO FIVE FEET INTERVALS.